

de	Montageanleitung
en	Mounting instructions
fr	Instructions de montage
sv	Monteringsinstruktion
nl	Montage-handleiding
it	Istruzioni di montaggio
fi	Asennusohje
es	Instrucciones de montaje
da	Monteringsvejledning
pl	Instrukcja montażu
cz	Montážní návod
hu	Szerelési útmutató
el	Οδηγίες εγκατάστασης
ru	Инструкция по установке
zh	安裝指導

Hilfsschalter
Auxiliary switch
Contact auxiliaire
Hjälpkontakt
Hulpschake-laar
Contatto ausiliario
Apukytkin
Contacto auxiliar
Hjælpe-kontakt
Przełącznik pomocniczy
Pomocný kontakt
Segédkap-csoló
Βοηθητικός διακόπτης
Вспомогательный выключатель
辅助开关




ASC1.6



SKB62 + ASC1.6 + ~~ASZ62.6~~



1



SKB60, SKB62..., SKC60, SKC62...

SKD60, SKD62...


2




3




4





5




de leicht anziehen
 en tighten slightly
 fr serrer sans forcer
 sv dra åt lätt
 nl licht aandraaien
 it fissare leggermente
 fi kiristää kevyesti
 es apretar suavemente
 da spændes let til
 pl dokreć lekko
 cz lehce utáhnout
 hu finoman meghúzni
 el σφίξτε με δύναμη
 zh 轻微地锁紧




6




7



de festziehen
 en tighten
 fr serrer à fond
 sv dra fast
 nl vastschroeven
 it fissare
 fi kiristää
 es atomillar
 da skrue fastgøres
 pl dokreść
 cz utáhněte
 hu erősen meghúzni
 el σφίξτε
 zh 锁紧




8



c1: ASC1.6

AC 24 V
 10 mA ... 4 A resistive
 max. 2 A inductive


9



10




de Montageanleitung
en Mounting instructions
fr Instructions de montage
sv Monteringsinstruktion
nl Montage-handleiding
it Istruzioni di montaggio
fi Asennusohje
es Instrucciones de montaje
da Monteringsvejledning
pl Instrukcja montażu
cz Montážní návod
hu Szerelési útmutató
el Οδηγίες εγκατάστασης
ru Инструкция по установке
zh 安裝指導

SKB60, SKB62...
SKC60, SKC62...

74 319 0324 0

SKD60, SKD62...



74 319 0325 0

