


- de Montageanleitung
- en Mounting instructions
- fr Instructions de montage
- sv Monteringsinstruktion
- nl Montage-aanwijzing
- it Istruzioni di montaggio
- fi Asennusohje
- es Instrucciones de montaje
- da Monteringsvejledning


QAC...
QFA...

QAC....




1814Z02

QFA...




1858Z02

A




1761Z10

B








1814M02

For US and Asia Pacific only:




1781Z06M

G	AC 24 V \pm 20 % / DC 13,5...35 V	B	
G0	GND	M	
U...	DC 0...10 V		
I ...	DC 4...20 m A	BS	
G...	DC 13,5...35 V	MS	
C +	com		
C -	com		


1781Z08

D

QAC...



QFA...



QFA...

